


# USER MANUAL

Model: BONAACK BT-1000 (Bluetooth Speaker)



Speakers Echo  
Speaker's Volume  
Power Light  
Pre Switch  
Power Switch

Music Volume  
Bluetooth & SD Card Switch  
Indicator Light  
Next Switch  
Play/Pause

## Structure

## Standard accessories

USB cable  
audio/recording cable

## HOW TO USE

1. Switch on/off: press the power button, the blue light will on/off (the lights of the microphone keeps flashing steadily)
2. Bluetooth connection: Press the mode switch, then the microphone Bluetooth is on (the lights disappears). Turn on the Bluetooth on your mobile phone and search for the Bluetooth name " Q78 ". Click and paired, the device will tick sound!(Note: The process of input password, enter 0000)
3. Playing music: turn on mobile phone music app such as kugou, download your favorite songs or accompaniment songs, volume could be adjusted by cellphone.
4. Adjusting sound: adjust voice volume or echo in suitable place
5. Start singing and have fun!

## HOW TO RECORD

1. Connect the audio cable, plug the micro USB port into pocket key and 3.5mm audio port into cellphone.
2. Open recording app like Apple Music and follow the using process, start recording.
- P.S. bluetooth will automatically disconnect when audio cable plug in.

## Status Reasons Solutions

LED does not light	Low power or changing cable not plugged in	Charge or check the charging cable
microphone not working	not turned on or the voice volume not adjusted	switch on or adjust the voice volume
No Reverberation	ECH key not adjusted	adjust ECH to a suitable place
Presence of noise	Environmental noise mobile phone signal interference	Adjust the distance between microphones and cellphone
Some types of mobile phone recording effect is poor	Phone does not match, phone chip processing ability that is weak	Restart the phone to try again or replace the phone
When playing music, staccato appears	Distant Bluetooth connection or obstructions between phone and device	Close to mobile phone, keep away from obstructions
Accompaniment sounds weak or no sound	Mobile phone volume low or music file quality bad	Higher phone volume download high quality music
Bluetooth cannot paired	Distant Bluetooth connection or already paired with other phone	Get close to phone or disconnect with other phone

Sound distortion when playing music

Volume too high/battery power is too low  
IOS system doesn't support bluetooth output  
Lower phone volume charge device  
Try android phones or other singing apps

## SHOW TECHNIQUE

1. When the battery voltage is too low, the product will automatically shutdown.
2. Using USB cable to connect with mobile phone standard jack, then the red light will light.
3. Normal charging 2 hours, charging is completed, the red light is automatically extinguished
4. Normal conditions works 4-8 hours.

## TECHNICAL SPECIFICATIONS

Microphone/Capacitance  
Output power:5W(Speaker Output)  
Frequency Range: 100Hz-10KHz  
Maximum sound pressure level: >115dB 1KHz THD<1%  
Reverb Mode: Echo sound reverberation  
Power Supply: Built-in Li-Ion Battery  
Battery Capacity: 2200mAh/7260mAh  
Charging Voltage: DC 5V

## WARRANTY DESCRIPTION

**30 days No Reason money back guarantee, 1 year warranty, and 24 hours friendly customer service.**

If: you are disappointed and even angry  
Please don't hesitate to contact our email:  
[support@bonaack.com](mailto:support@bonaack.com)

If: You just want to help us make this better,  
we are more than happy to hear from you,  
and provide 6 month warranty to you.

We can only be able to offer returns/exchanges for orders placed through BONAACK Direct